COMPARTMENT LOCKS

USER'S MANUAL & INSTALLATION GUIDE





TABLE OF CONTENTS

- Welcome Contents
- 1 How to Install Your New Compartment Locks
- Cam Lock Install Order
- Full Walkthrough Video Instructions
- Frequently Asked Questions

WELCOME TO THE FAMILY!



Thanks for purchasing our Latch.it RV Compartment Lock! We are a family owned American business that cares about your safety and security!



Please review, read and understand ALL instructions to ensure proper functionality.

If you have any questions or concerns, don't hesitate to reach out to us, we are always available at info@latchit.org

SEE FULL VIDEO INSTRUCTIONS AT www.latchit.org

102 How to Install Your New Compartment Locks

- 1. Gather the following tools:
 - a) Adjustable Open-End Wrench.
 - b) A 7/16" socket to tighten the Nut.
 - c) A 7/8" socket to tighten the Hex Nut.
- 2. Attach **O-ring** to Cam Lock Body.
- 3. Slide **Cam Lock Body** through compartment lock hole and screw on **Hex Nut** to hold it in place.
- 4. Place **Anti-Slip Washer** in correct orientation so it fits FLAT with the lock body.
- 5. Place Latch onto Cam Lock Body.
- 6. Attach **Locking Washer** and hand screw **Nut**. Tighten nut to hold everything in place. **Do not over tighten.**





IF KEY DOES NOT COME OUT IN LOCKED AND UNLOCKED POSITION, THEN ANTI-SLIP WASHER IS INSTALLED IN WRONG ORIENTATION. FLIP IT, AND RE-INSTALL IT.



RV STORAGE DOOR

OR

FILE CABINET DOOR

OR

DESK DRAWER DOOR

INSTALL ORDER















Don't want to READ all the instructions?



We got your back!



Simply scan the QR code with your smart phone camera & head over to the How-To-Video section of the site.



OR VISIT latchit.org/how-to-videos



Questions, stuck on something, or simply want to to talk to an expert?



info@latchit.org



www.latchit.org



/LATCH.IT.LOCKS



@latch.it